# **TCIL Series Troubleshooting Guide**

**TCIL Series 12-24VDC** 

Last Update: 07/16/20

### **Identify the Sign Problem:**

Follow the flowchart to diagnose the symptoms


There are some LEDs out A message is lit that shouldn't be The display is flickering

Pg 4

The entire display is out

#### **Tools Needed:**

Philips head screwdriver Multi-meter





Always turn off the power to the sign prior to opening the cabinet. Disconnect the power wires going to the sign.

**Note:** Make appropriate wiring connections per local codes.

### **Description of Normal Operation for the Signal's Internal Power Supply**

Diagnostic LEDs are included on the internal power supply to aid in verifying that input power is present and is being transferred to the sign face through the output connectors.

#### +12V LED

This LED illuminates Green when 12-24VDC power is applied to the internal power supply's input power pigtail. **Note:** The transformer on the power supply converts 12-24VDC power to +12V.

#### A Output LED

Illuminates with power applied to Blue wire on the input power pigtail

#### **C Output LED**


Illuminates with power applied to Red wire on the input power pigtail


#### **B Output LED** (Used for third message ONLY)

Illuminates with power applied to Yellow wire on the input power pigtail

#### **Output Connectors**

These connectors transfer power from the internal power supply to the sign face to illuminate the individual message(s).






### Problem: There are some LEDs out

**TCIL Series 12-24VDC** 


Last Update: 07/16/20




## Problem: A message is lit that shouldn't be

**TCIL Series 12-24VDC** 

Last Update: 07/16/20





## Problem: Entire display is out

**TCIL Series 12-24VDC** 

Last Update: 07/16/20

